






STEP 7




B




STEP 8




STEP 9





STEP 10




STEP 11




STEP 12




STEP 13




STEP 14




STEP 15



STEP 16




STEP 17



















STEP 18


COMBINE B C




STEP 19







STEP 35



ATTACH THE MODEL TO THE TRIANGLE POWER BASE

