




STEP
11




STEP
12




STEP
13




STEP
14





STEP
15




STEP
16




STEP
17




STEP
18




STEP
19




STEP
20



STEP
21




STEP
22



STEP
23

COMBINE


B



STEP
24

COMBINE

A



ATTACH MODEL TO THE TRIANGLE
POWER BASE WITH THE PEG CORD

STEP
25

