






STEP  
10





STEP  
11




STEP  
12




STEP  
13




STEP  
14




STEP  
15





STEP  
16




STEP  
17




STEP  
18




STEP  
19




STEP  
20




STEP  
21  
COMBINE  
A




STEP  
22  
COMBINE  
C



STEP  
23



STEP  
24  
COMBINE  
B



ATTACH MODEL TO TRIANGLE POWER BASE

STEP  
25

