




STEP
9




STEP
10




STEP
11




STEP
12




STEP
13




STEP
14




STEP
15




STEP
16





STEP
17




STEP
18




STEP
19




STEP
20




STEP
21




STEP
22




STEP
23




STEP
24




STEP
25




STEP
26




STEP
27




D




STEP
28




STEP
29




STEP
30




STEP
31




STEP
32
COMBINE
B



STEP
33
COMBINE
A




E




STEP
34


COMBINE
D




STEP
35



STEP
36



STEP
37
COMBINE
C



STEP
38

ATTACH MODEL TO THE TRIANGLE POWER BASE

