



This diagram illustrates the assembly of a 1x3 Technic brick with a 1x3 Technic axle and a 1x3 Technic axle. The assembly is shown in three stages: 1. A 1x3 Technic brick is shown with a 1x3 Technic axle inserted into its side hole. 2. A 1x3 Technic axle is shown with a 1x3 Technic axle inserted into its side hole. 3. The final assembly is shown with the 1x3 Technic brick and the 1x3 Technic axle connected by the 1x3 Technic axle.


STEP
7





STEP
8




STEP
9




STEP
10




STEP
11
COMBINE
A




STEP
12



STEP
13
COMBINE
B



STEP
14



ATTACH MODEL TO TRIANGLE POWER BASE

STEP
15

